


Wireless client configuration

Step 1 : Open ZyXEL Utility for Wireless connection



Step 2: Configure and select a profile to connect to the AP. Make sure the SSID is configured in the profile to match the AP.

